


DRIVER BEHAVIOR

KEEP DRIVERS SAFE.

- Track driver behavior for your entire over the road fleet
- Custom set parameters and scorecards help manage your drivers
- Nullify a driver behavior occurrence from scorecard by simply checking a box
- Notification include high and low severity configurations for:
 - Speeding
 - Harsh Braking
 - Harsh Turning
 - Hard Acceleration
- Driver scorecards can be configured to any specification with scheduled email delivery
- Driver identity can be monitored with key fobs or cameras



FLEET INTELLIGENCE Powered by FORESIGHT[®] INTELLIGENCE[™]

15333 N. Pima Rd. Ste 165
Scottsdale, AZ 85260
www.fleetintelligenceglobal.com
info@fleetintelligenceglobal.com
877-57-FLEET

SUBSCRIPTION LEVELS

All levels include Express

Feature	Express	Inspection Module	Utilization/Fault Codes Module	Maintenance Module	Platinum
All Assets In One Place	X	X	X	X	X
Map, Location	X	X	X	X	X
Hours, Mileage	X	X	X	X	X
Breadcrumb Detail	X	X	X	X	X
Geofence, Curfew, & Tamper Alerts	X	X	X	X	X
Jobsite Locations	X	X	X	X	X
Distance Traveled Report	X	X	X	X	X
Driver Behavior	X	X	X	X	X
Driver ID	X	X	X	X	X
Rental Connect	X	X	X	X	X
Unlimited Users	X	X	X	X	X
Onboarding & Training	X	X	X	X	X
Mobile App	X	X	X	X	X
Email Reports	X	X	X	X	X
Cameras	X	X	X	X	X
Custom Built Inspections		X			X
Photos & Videos		X			X
Multiple Languages		X			X
Idle Time			X		X
Health Alerts			X		X
Engine Code & Diagnostics			X		X
High/Low Utilization			X		X
Fuel Burn			X		X
Fuel Tracking				X	X
Maintenance Plans by Hours, Distance, & Time				X	X
Integrated Work Orders				X	X
Equipment Scheduler	ADD-ON	ADD-ON	ADD-ON	ADD-ON	ADD-ON
Route Optimization	ADD-ON	ADD-ON	ADD-ON	ADD-ON	ADD-ON
ELD & HOS	ADD-ON	ADD-ON	ADD-ON	ADD-ON	ADD-ON